

Season	Dates	Hours Ending	Requirement MW
Winter	Nov. 1–Feb. 28	HE 5 – 10, HE 17 – 24	750
		HE 1, HE 11	650
		HE 2 – 4, HE 12 – 16	550
Spring	March 1–April 30	HE 19 – 1, HE 6 – 9	750
		HE 2, HE 10	650
		HE 3 – 5, HE 11 – 18	550
Summer	May 1–Sept. 15	HE 5 – 1	750
		HE 2	650
		HE 3 – 4	550
Fall	Sept. 15–Oct. 31	HE 6 – 9, HE 18 – 24	750
		HE 1, HE 10	650
		HE 2 – 5, HE 11 – 17	550