# **DR Hub Event Acknowledgement Client** v1.0

This is a generic Windows standalone polling application that periodically polls PJM's DR Hub system for new events and acknowledges the receipt of these events. This software is provided as-is and is not supported by PJM.

This client will poll for the following Event types:

- Real Time economic energy events
- Synchronized Reserve events
- Load Management (Emergency DR) events
- Emergency Energy Only events

This is a working sample provided with source code and users are free to modify the source code.

Sources are provided in pim-drhub-poller.jar.jar.

## Directory structure:

### EventsAckClient

-- Documentation docs |---download -- Downloaded Files

-- Log output from execution |---logs logs upload

-- Files to be uploaded (if applicable) |----

Files

Config.properties Pim-drhub-poller.jar Run.bat

### Installing the client on Windows machine

- 1. Copy the drhub-poller-(version number).zip file to c:\
- 2. Open the command window, type cd c:\, press Enter
- 3. type mkdir EventsAckClient, press Enter
- 4. type cd EventsAckClient, press Enter
- 5. Type unzip c:\ drhub-poller-(version number).zip
- 6. Note: Only one instance of the client may run for each CSP (org)

#### **Dependencies**

- The proper operation of this client depends on the Java framework. A run time version of java must exist on the executing client and be visible by the program.
- If execution of Run.bat results in errors indicating Java cannot found you will need to add the local java runtime path to the Run.bat file. This will enable the client where to find the appropriate files.
- Java 6 or higher is required to run the CLI.

- Example of Run.bat with the java path defined.
  - o set PATH=C:\MyStuff\jdk1.7.0 55\jre\bin;%PATH%
  - o java -jar pjm-drhub-poller.jar

## **Configuring the client**

• Edit the ../config/configuration.properties file as described in the file

## **Configuration Settings**

- The Web Service URL: Assign the appropriate URL (Sandbox or Product) to the polling agent configuration. An option for each is provided in the configuration file.
- User name and password: the user name and password designated for polling DR
  Events. We recommend that a unique eSuite account configured as a System ID be
  used for polling. Do not use your personal eSuite UI account for polling.
- Logging: Within the config.properties file, logging output may be adjusted between TRACE and ERROR depending on the level of output desired.
- Interval: The interval value sets the time between each polling service call. One minutes is the default and recommended interval for all Event Types
- Retention Day: This number (in days) sets the level of file retention for the polling agent. All event and log files older than the current date – number of retention day will be removed.
- Event Types: The option exists to include or omit event polling by type. The configuration file contains an option for each type. Setting the type to True will include this option when polling for new events. Setting an event to False will omit.

## **Running the client**

Execute the below from the command prompt.

c:\EventsAckClient> run.bat

### **Terminating the client**

Press ctrl-c on the command window and respond with 'y'

## **Checking events received**

The following Event files are created each day by directory: Events are stored by Type Name in the folders reflecting the date downloaded.

../dowload/<date?/Event\_Type-<YYYY-MM-DD>.xml

## **Checking acknowledged events**

The log directory maintains a log of events and the dates on which they were acknowledged.

### **Common issues**

- \* Connection refused connecting to web service
- Configure the config.properties file, property "end point" to point to correct Web service url.
- \* Invalid credentials passed
- Configure the config.properties file , property 'username' and 'password' with correct credentials
- USERID should have Manage All permission level to Execute all Web Service requests. Others will have limited access.